



How to Install the Wall-Mount Bracket




Apply double-sided tape to the back of the wall-mount bracket, then attach the bracket to the wall.




About 10 minutes after attaching the bracket to the wall, hang the trash can on the bracket.

How to Install the Over-Door Bracket




Hang the over-door bracket on the top edge of the door as shown.




Secure the trash can to the over-door bracket as shown.


How to Empty the Trash Can



Open the front door and pull out the bag.



Cut the bag with the safety blade inside the door.



Pull the cut end of the bag and tie a knot.



CAUTION

- Washing with water can damage the unit.
- Dispose of waste in standard garbage bags.
- Avoid strong impacts and excessive force.
- Suffocation risk: keep Refills away from children.
- Chrome-plated models can discolor if exposed to salty substances for a long time.
- Genuine MAGIKAN Refill users get free repairs for defects, even after the 1-year warranty (while parts last).




MAGIKAN BiiNu is a combination of BLANC (pure white, clean) + NEW and BIN + NEW. BIINOO becomes BiiNu: a clean, pure and new trash can, like 'biinu' (soap in Korean).

MAGIKAN
BiiNu

INSTRUCTION MANUAL


Parts of the Unit



* To open or close the front door, gently turn the round lever.

Accessories

* Accessories are consumables and can be purchased separately.



How to Replace the Refill

