




How to Install the Wall-Mount Bracket


- 

Stick double-sided tape to the back of the wall bracket.
- 


Peel off the tape backing and press the bracket on the wall.
- 

Wait about 10 minutes, then hang the trash can on the bracket.

How to Install on a Cabinet Door

- 


Hang the cabinet bracket on the top of the door as shown.


If the cabinet door is thin, insert the spacer blocks to fit.
- 

Secure the trash can to the cabinet bracket as shown.

How to Empty the Trash Can

- 

Open the front door and pull out the bag.
- 

Cut the bag with the safety blade inside the door.
- 

Pull the cut end of the bag and tie a knot.



CAUTION

- Washing with water can damage the unit.
- Dispose of waste in standard garbage bags.
- Chrome-plated models can discolor if exposed to salty substances for a long time.
- Genuine MAGIKAN Refill users get free repairs for defects, even after the 1-year warranty (while parts last).
- Avoid strong impacts and do not use excessive force on the product.
- Suffocation risk: keep Refills away from children.




MAGIKAN

N . E . Ware

INSTRUCTION MANUAL


Parts of the Unit



*** To open or close the front door, gently turn the round lever.**

Accessories

* Accessories are consumables and can be purchased separately.



How to Replace the Refill

- Open the lid, remove the frame, then slide the Refill cartridge out along the arrows.
- Slip the Refill between the cartridge and its flap, then peel off the paper band.
- Grab the outer edge of the Refill and pull it straight up.
- Push the raised part of the Refill down into the cartridge.
- Put the cartridge, with the Refill in place, back into the unit.
- Pull the Refill down and tie a knot.